




Quick Start Guide




IMPORTANT:

 ***Read carefully the SkyTrak Safety and Product Information Guide before setup or use of the SkyTrak™ system. Failure to read and follow the Safety and Product Information Guide may cause serious injury or death.***


The SkyTrak system specifications and functionality are constantly evolving, and we may update or change the SkyTrak system in whole or in part, without notice to you. Such updates may be required for you to use new functionality, access new courses or features, or continue to access and use existing courses and features. The courses and features available for use on the SkyTrak system change from time to time, and not all courses or features previously offered will be available. Some features require an annual subscription.

The software in the SkyTrak system is licensed and not sold to you, and is subject to the End User License Agreement set forth in the SkyTrak Safety and Product Information Guide.


Product Overview



What's in the Box



SkyTrak® Personal Launch Monitor



USB Cable



Quick Start and Product & Safety Information Guides

Let's Get Started!

Setting up your SkyTrak for the first time is a simple 3-step process:

1


Download the SkyTrak Mobile Software

Find the SkyTrak software in the Apple® App StoreSM or follow a link to the application on www.skytrakgolf.com

2

Register Your SkyTrak

Launch the SkyTrak software on your iPad® and follow the instructions in the SkyTrak app on your iPad.*



Select the “Create Account” option to create a SkyTrak online account.

Next, select “Register” to register your SkyTrak. Your SkyTrak’s unique serial number will display and it will be registered with SkyTrak

** Your SkyTrak must be registered within 30 days of purchase. SkyTrak comes with basic functionality in-the-box and may come with some trial features, enabling you to start playing immediately. Advanced features are available with a SkyTrak annual subscription plan, which can be purchased at www.skytrakgolf.com.*

SETUP TIP: Once SkyTrak has been successfully configured and connected with the software on your iPad, all three LEDs will turn green and you will see a red laser dot projected onto your hitting surface.

3

Pair Skytrak With Your iPad

You can pair SkyTrak with your iPad in two ways:

- Via a direct Wi-Fi connection **OR**
- Through your home network

Direct Wi-Fi Connection

Follow the instructions in the SkyTrak software application to pair your iPad directly to SkyTrak's via its Wi-Fi signal. Your iPad will NOT have an internet connection when connected in this manner.



Network Connection *(recommended)*

SkyTrak can use your wireless (Wi-Fi) home network to pair with your iPad by connecting to your wireless network router, just like your computer and mobile devices do. SkyTrak will communicate with the software on your iPad through your router. Plus, you will retain access to the internet on your iPad.



Play!

SETUP TIP: Follow the Wi-Fi configuration steps in the SkyTrak software to select your desired connection mode. To make changes to your connection, access the Connection Wizard near the bottom of the main dashboard of the SkyTrak software at any time.

Powering On/Off

1. To turn on SkyTrak, press the POWER button.
2. The Power LED (bottom) will turn **GREEN** and you can start connecting SkyTrak to your iPad.
3. To turn off SkyTrak, press the Power button again.

Charging Your SkyTrak

SkyTrak contains a Lithium-polymer rechargeable battery that can operate up to 5 hours on a full charge.

1. Charge SkyTrak for 6 hours prior to initial use (NOTE: to charge, SkyTrak must be turned OFF).
2. Plug the USB cable into the USB port of a computer that is powered on or use a compatible, SkyTrak-supplied USB wall charger to charge SkyTrak.
3. The Power LED will turn **AMBER** when SkyTrak is charging.

Setting Up Your Space for SkyTrak


Before playing with SkyTrak the first time, be sure to remove the protective film from its optics lens and to fully charge its battery.

To reduce the risk of injury or property damage, it is recommended that the SkyTrak system be set up using the guidelines below. Please ensure that you have created enough space around you to safely play with SkyTrak and that you heed all applicable safety precautions at all times.

SETUP TIP: For optimum performance, it is recommended that you use a hitting mat for both indoor and outdoor use.

Minimum Unobstructed Area Dimensions


- Ceiling height: Safe ceiling height varies and depends on your physical height and the length of your club.
- Length: 10 feet (3,35m)
- Width: 10 feet (3,35m)




CAUTION: Always use a safety net and a hitting mat specifically designed for golf if the hitting area or the ball flight area is restricted such as indoors or in the back yard of a residence.

Placement of Your Golf Ball


- Make sure SkyTrak is raised level with the hitting surface.



- Place SkyTrak parallel to your intended line of play. Depending on your set up, this may mean your target is not the center of the net.



- Once SkyTrak is properly connected to the app on your mobile device, it will display a red laser dot on your hitting surface. Place a clean, white golf ball on the red dot.






























SETUP TIP: For optimum spin results, place the ball on the laser dot with some kind of marking on the golf ball, such as its brand logo, facing toward SkyTrak's lens prior to hitting.

Helpful Tips & Care Instructions

- SkyTrak uses advanced optics that are located behind its lens. Scratches and dust or other issues that impact the lens quality may interfere with SkyTrak's operation. Keeping the lens clean and scratch-free will ensure the measurement accuracy and longevity of your SkyTrak system.
- Use a clean, damp cotton cloth to clean the lens in a single wipe. **Do not use any chemicals to clean the lens.**
- Carrying cases to keep your SkyTrak protected and other accessories are available for purchase at www.skytrakgolf.com
- Never disconnect or turn off your SkyTrak while it is syncing. Wait until it is finished communicating before you disconnect it, power it off, or power off your mobile device.
- Don't expose your SkyTrak to extreme temperatures. Hot or cold conditions may affect performance.
- Don't allow your SkyTrak to get wet.
- Don't drop your SkyTrak, or hit your SkyTrak with your golf club or golf ball.
- Compatibility of your SkyTrak device with mobile devices, like tablet computers, varies by mobile device and its operating system and display capabilities, which change often and are outside the control of SkyTrak. Not all mobile devices are compatible with your SkyTrak device. To view a list of currently compatible devices, go to www.skytrakgolf.com
- Fully charge the battery prior to playing with your SkyTrak.

LED Color Code Chart

Use this chart to identify or troubleshoot SkyTrak's various operational modes.

Power LED	Wi-Fi LED	Ready LED	Description
			Battery is low and SkyTrak is about to turn itself off. Please charge your SkyTrak as soon as possible.
			SkyTrak is in Direct Connect Mode, waiting for a connection with the SkyTrak Application on your tablet.
			SkyTrak is in Network Mode and it is attempting to locate and connect to a known Wi-Fi network.
			SkyTrak is in Network Mode and it has located a known Wi-Fi network. It is attempting to connect to that network.
			SkyTrak is in Network Mode and it is connected to a known network. It is waiting for a connection with the software on your tablet.
			SkyTrak is connected to the Application. If the Ready LED is not turning green quickly, Please check to see if SkyTrak is tilted instead of being level.
			SkyTrak is ready for your next shot.
			SkyTrak is charging.
			SkyTrak is charging, but the power of the charger is not adequate, it may take a long time for your SkyTrak to charge.

Troubleshooting

Problem	Solution
When charging, 'Power' LED does not come on (AMBER)	Press and hold the Power button for 5 seconds. Make sure the USB cable has power. Try other ports on your computer or use a compatible USB wall charger. SkyTrak should be turned OFF to charge.
All 3 LED's turn red and unit turns off after 15 seconds	Battery is low. Connect the USB cable and charge the unit. The Power LED will turn off when SkyTrak is fully charged and ready to go.
'Wi-Fi' LED is not turning green	First, ensure that your SkyTrak is connected to the Wi-Fi network. Then start the SkyTrak software on your iPad and allow it to load. When the application is open, SkyTrak's LEDs will show whether it successfully connected.
Wi-Fi and Power LEDs are green, but 'Ready' (top) LED is red	Your SkyTrak may have been triggered by a waggle or other club movement. If you'll wait a few seconds, it should turn green again. If it still doesn't turn green, you should check your Wi-Fi connection and restart the application on your iPad.
Results seem inaccurate	Be sure to position the ball correctly on the red dot and make sure the unit sits level with the hitting surface. If using a tee, make sure the base of the tee is on the red dot.

Should this Trouble Shooting Guide not answer your question, please refer to the Frequently Asked Questions at www.skytrakgolf.com.



Powered by:



©2014 SkyTrak, LLC. All Rights Reserved.
Patents Pending.

SkyTrak™ is a trademark owned by SkyTrak, LLC. iPad® and Apple® App StoreSM are trademarks of Apple, Inc., registered in the U.S. and other countries. Other trademarks and trade names are those of their respective owners. Use of marks not owned by SkyTrak, LLC, is under license.

All content within this Guide is copyrighted by SkyTrak, LLC and may not be reprinted without permission. The content of this Guide is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by SkyTrak, LLC. SkyTrak, LLC assumes no responsibility or liability for any errors or inaccuracies that may appear in the informational content contained in this Guide.